

ITEM T80/009

SUBJECT: INSTALLATION OF FOG LIGHTS

MODELS: TR7, TR8

When fitting fog lights to Jaguar Rover Triumph Inc. vehicles it is essential to follow the installation instructions supplied with the fog light kit available from Jaguar Rover Triumph Inc. parts sources.

The relay supplied and referred to in the instructions protects the fog light circuit and other lighting systems. Damage to the electrical wiring could occur if the fitting instructions are bypassed for convenience purposes.

Item #12 in the TR7/8 installation instructions may be deleted on certain 1980 vehicles as the fog lamp indicator light is an integral part of the switch.

The lamp mounting brackets must be used where specified as they are designed to ensure that the fog lights meet various state regulations with regard to height, etc.

NOTE: Fog lights must only operate in the low beam headlights position.

Early Fog Light Kit P/N BLM 105700

Late Fog Light Kit P/N JRT 105720 (with lamp covers)

P.W.B.