

TECHNICAL SERVICE BULLETIN

77-B-11

NO.



Triumph

November, 1977

SUBJECT:

LATE 1977 and 1978 WIRING DIAGRAMS

MODELS:

TR7

On late model TR7's the wiring diagram has been changed extensively. The diagram on the attached page is reproduced for your convenience.

Provided Courtesy Triumph Wedge Owners Association
<http://www.triumphwedgeowners.org>

KEY TO THE 1978 TR7 WIRING DIAGRAM

- | | | | |
|------------------------------------|----------------------------------|--|--|
| 1. Battery | 31. R.H. side marker | 61. Boot lamp switch | 90. Tank unit |
| 2. Alternator | 32. L.H. side marker | 62. F.A.S.D. | 91. Low fuel delay unit |
| 3. Starter motor | 33. R.H. side indicator | 63. Engine thermostat | 92. Brake pressure differential switch |
| 4. Starter relay | 34. L.H. side indicator | 64. Reverse light switch | 93. Handbrake switch |
| 5. R.H. head lamp relay | 35. Front fog lamps junction | 65. Stop light switch | 94. Oil pressure switch |
| 6. L.H. head lamp relay | 36. Heater control illumination | 66. Oil warning light | 95. Ignition warning light |
| 7. Head lamp motor circuit breaker | 37. Borg Warner illumination | 67. Ignition switch | 96. Oil warning light |
| 8. Start inhibit switch (Auto) | 38. Cigar lighter illumination | 68. Anti run on valve | 97. Brake warning light |
| 9. Ignition switch | 39. Panel rheostat | 69. Oil pressure switch | 98. Choke warning light |
| 10. Buzzer timer unit | 40. Switch panel illumination | 70. Anti run on valve—
California market only | 99. Low fuel warning light |
| 11. L.H. Head lamp motor | 41. Panel illumination | 71. Heated rear screen—TR7 coupe | 100. Choke warning light switch |
| 12. R.H. Head lamp motor | 42. Rear fog lamps illumination | 72. Heated rear screen switch | 101. Fuel gauge |
| 13. Master light switch | 43. Rear fog lamps warning light | 73. Heated rear screen warning light | 102. Tachometer |
| 14. Seat belt warning light | 44. Fog Switch | 74. Heated rear screen | 103. Temperature gauge |
| 15. Buckle switch | 45. L.H. indicator warning light | 75. L.H. side indicator | 104. Battery condition indicator |
| 16. Door switch | 46. R.H. indicator warning light | 76. R.H. side indicator | 105. Temperature transmitter |
| 17. Audible warning | 47. Flasher unit | 77. L.H. stop light | 106. Thermostat |
| 18. Cigar lighter | 48. Direction indicator switch | 78. R.H. stop light | 107. Heater/air conditioning blower unit |
| 19. Loudspeakers | 49. Horn push | 79. L.H. reverse light | 108. Air conditioning circuit |
| 20. Radio | 50. Horn relay | 80. R.H. reverse light | 109. R.H. condenser fan |
| 21. Hazard unit | 51. Horns | 81. Number plate lights | 110. L.H. condenser fan |
| 22. Hazard switch | 52. Windscreen wiper motor | 82. R.H. sidemarker | 111. Radiator thermostat |
| 23. Main/dip/flash switch | 53. Windscreen wipe/wash switch | 83. R.H. tail lights | 112. Fan relay |
| 24. Main beam warning light | 54. Windscreen washer motor | 84. L.H. tail lights | 113. Full throttle cut off switch |
| 25. R.H. main beam | 55. Door switch | 85. L.H. sidemarker | 114. Air conditioning cut out |
| 26. L.H. main beam | 56. Courtesy light | 86. Drive resistor | 115. Air conditioning relay |
| 27. R.H. dip beam | 57. Door switch | 87. Eureka wire (1.3-1.5Ω) | 116. Delay unit |
| 28. L.H. dip beam | 58. Courtesy light | 88. Distributor | 117. Throttle jack |
| 29. R.H. side light | 59. Clock | 89. 6v. coil | 118. Ranco valve high pressure cut off |
| 30. L.H. side light | 60. Boot lamp | | 119. Clutch |
| | | | 120. Clutch relay |

CABLE COLOUR CODE

N. Brown	P. Purple	W. White	K. Pink
U. Blue	G. Green	Y. Yellow	O. Orange
R. Red	LG. Light Green	B. Black	S. Slate

